


# DORANI<sup>®</sup>

## REMOTE VIEWING

**SYSTEM DEFAULT PASSWORD : 123456**




**Ensure network cable is connected**

**and green light is flashing**

Download **Dorani IP Viewer** from the app store or google play.




### Step1




Select 'sign up' from the home page

### Step 2




Enter e-mail address and verify code which is sent to your e-mail address

### Step 3



Enter password and select 'sign up'. You will be directed back to the screen on Step 1. Enter e-mail and password, Select 'Login'


#### Step 4



Select 'Menu'


A pop up window may appear asking you if you would like to add a device. Adding here will only work on wifi so skip if off site viewing is required

#### Step 5




Select 'Devices'

#### Step 6




Select '+Add'

#### Step 7




Select 'Scan'

#### Step 8



Scan the QR code from  
-Page 1 of start up or  
-Bottom of NVR

#### Step 9



Name the device then,  
Start Live View

**NOTE :** If your mobile is on WIFI and your NVR is connected to the network, the app will automatically detect the device. If you use the auto connect feature via WIFI, remote viewing will only work while in the same WIFI area, not on 4G.